

Product Data Sheet

Fridge/Freezer Thermometer with Alarm

Reference 91000-009/A

Specifications

- -50+70°C / -58+158°F
- Resolution : 0.1°
- Accuracy: $\pm 1^\circ\text{C}$ / $\pm 1.8^\circ\text{F}$
- Câble : 1 m
- Programmable Alarm
- IN/OUT Temp.
- MAX/MIN Temp
- Magnetic back
- In Blister pack



Instructions

TO START. Firmly attach the probe holder with adhesive tape onto the desired position inside the fridge/freezer. Insert the probe into its holder. Place the thermometer in the desired space outside the fridge/freezer by using the magnets at the back of the thermometer. Press [°C/°F] to select temperature unit.

IN/OUT TEMPERATURE. Press [ROOM/FRIDGE] to display room or fridge/freezer temperature.

MAXIMUM-MINIMUM FUNCTION. Press [MAX/MIN] to display maximum measured value, press the button once more to display minimum measured value, press the button again to return to normal display. Press and hold [MAX/MIN] for about 2 seconds to reset memory to current reading.

ALARM FUNCTION. Press and hold  for about 2 seconds (**HI & FRIDGE** will flash). Press  to set the alarm high limit. Press  again (**HI & FRIDGE** will flash). Press  to set the alarm low limit. Press  once more to end setting. If the fridge sensor reading is out of the set limit the alarm will sound. Press  to switch the alarm off or on.



Do not put the thermometer inside the fridge/freezer. Put only the probe. Do not use in oven or in a microwave oven. Do not put in dishwasher. If the display becomes dim, change the battery.

Alla France

Z.I. du Bompas - 13, rue du Bompas - Chemillé - 49120 Chemillé-en-Anjou - FRANCE
Tél. + 33 (0)2 41 30 55 08 - Fax +33 (0)2 41 30 34 67


France