

Product Data Sheet

Digital Oven Thermometer
Reference 91000-002/F

Specifications

- -50+300°C / -58+572°F
- Display: 0.1°
- Accuracy: $\pm 1^{\circ}\text{C}$ (-20+100°C) / $\pm 2^{\circ}\text{F}$ (-4+212°F) otherwise $\pm 2^{\circ}\text{C}/\pm 4^{\circ}\text{F}$
- Curved stainless steel probe: 150 mm - Ø 4 mm
- Stainless Steel Cable: 100 cm
- Alarm
- Timer 99H-59M
- MAX/MIN
- Magnet
- Compatible with Electro magnetic induction
- 1 AAA battery
- In French Cooking Blister pack



*Do not use excessive force when inserting the probe. Do not use the thermometer's case in oven.
Do not use in a microwave oven. Do not put in a dish washer. Do not immerse the case in water.
After each measurement clean the probe with a cloth. If the display becomes dim, replace the battery.*







Instructions

Press [°C/°F] for 3 seconds, to choose the unit of measure.

MAXIMUM/MINIMUM MEMORY

Press [MAX/MIN] button once will display the maximum reading and a MAX symbol will flash. Pressing [MAX/MIN] once more will show the minimum reading and a MIN symbol will flash. Pressing [MAX/MIN] button again will return to normal display. Press [MAX/MIN] for 3 seconds, to reset the memory.

TEMPERATURE ALARM SETTING

Press [SET] button once : OFF will flash. Use the  and  keys to set the desired alarm high limit. Press [SET] button once more and OFF will flash. Use the  and  keys to set the desired alarm low limit. Press [SET] again to finish the setting. Press [START/STOP] to activate/desactivate the Alarm function. If the temperature value is out of the set limit then the alarm will sound. Press any button to stop the alarm sound but  or  will flash to show that the temperature is out of limit.

TIMER

Press [HOUR] and [MIN] to program the timer. Press [START] to start the countdown. When the desired time has passed the alarm will sound. To stop, press [STOP]. For reset, simultaneously press [HOUR] and [MIN].

DATA HOLD

Press [HOLD] button to retain the display reading and the [HOLD] symbol will flash. Press [HOLD] button again to return to normal display.

Alla France


France